CALLISTO

CRUISE ALARMING

ESPA-X SERVER INTERFACE DESCRIPTION

Table Of Contents

ESPA-X Server interface description 3
ESPA-X Server interface description 3
Copyright Information, Disclaimer 5

ESPA-X Server interface description

Overview

The *Alarming* application handles alarms (i.e., configuring alarm groups and activating alarms) from different sources:

- ESPA 4.4.4 via COM ports
- via ESPA-X clients
- manually via the web GUI
- via REST web service

Services button

These alarms are sent as push messages to the configured groups of phones set as alarm destinations. The phone displays the most recent alarm message; the five most recent alarms can be viewed by pressing the *Services* button on the phone.

For more information on configuring an ESPA-X server, refer to the chapter ESPA configuration in the administration manual.

ESPA-X supported messages

LOGIN

To start a session, an ESPA-X client needs to send a REQ.LOGIN message immediately after the connection to the server is established. Every request coming before the REQ.LOGIN request will be refused with the response code 407 (*authentication required*).

If the login is successful, the server will send a RSP.LOGIN response with response code 200 (*OK*) and a *sessionID* will be provided.

During a session, the *sessionID* provided in the RSP.LOGIN response must be used in every request by the client.

LOGOUT

When the server receives a REQ.LOGOUT message from the client, the Callisto ESPA-X server will disconnect the client and terminate the connection.

HEARTBEAT

A HEARTBEAT message needs to be sent from the client constantly within the defined interval. If an interval passes without Callisto receiving a HEARTBEAT message, the client is disconnected and the session will be terminated.

P-START

When call/alarm is triggered from a client, a P-START message is sent. The most important fields in the P-START message recognized by the Callisto ESPA-X server are:

CP-GROUPID:	The group number (address) which identifies the group of destinations which will be notified. See chapter Alarm groups in the administration manual.
CP-TEXTMSG:	A text message which will be sent to all destinations of the alarm group.

When the P-START message is received, Callisto immediately notifies the alarm group via push notifications.Also, a response (RSP.P-START) is sent including the following fields:

RSP.P-START

RSP-CODE	A 3-digit response code. Callisto responds with either of these codes: • 200: request processed successfully • 407: authentication required
RSP-REASON	A text relating to the RSP-CODE (either “OK” or “Authentication required”)
CP-PR-REF	The process reference received from client in the P-START request
SP-PR-TAN	The process transaction number of the server

Immediately after RSP.P-START, Callisto sends the following indications to the client: P-STARTED and P-ENDED (on server side, the process is ended immediately after the push notifications have been sent).

P-STARTED

SP-STATUS	Always returns “Active”
SP-CREATED	The time when the process started
CP-PR-REF	The process reference received from client in the P-START request
SP-PR-TAN	The process transaction number of the server

P-ENDED

SP-RESULT	None
SP-ENDREASON	Always returns “Finished”
SP-CREATED	The time when the process ended
CP-PR-REF	The process reference received from client in the P-START request
SP-PR-TAN	The process transaction number of the server
CP-GROUPID	The group number (address) which identifies the group of destinations which will be notified. See chapter Alarm groups in the administration manual.
CP-PHONENO	The phone number to which call is addressed

P-STOP

The *Process Stop* request message (REQ.P-STOP) is supported by Callisto but doesn’t have any effect on the process control because Callisto sends push notifications to a group of endpoints. Currently, this request is reserved for future use. Callisto always responds with 200 "OK" upon receiving a RSP.P-STOP message.

Copyright

Copyright © 2026 CTModule AG; All Rights Reserved

This document contains proprietary information of CTModule AG. No part of the work described herein may be reproduced. Reverse engineering of the hardware or software is prohibited and is protected by patent law.

This material or any portion of it may not be copied in any form or by any means, stored in a retrieval system, adopted or transmitted in any form or by any means (electronic, mechanical, photographic, graphic, optic or otherwise), or translated to any language or computer language without the prior written permission of CTModule AG.

The information in this document is subject to change without notice. CTModule AG makes no representation or warranties with respect to the contents herein and shall not be responsible for any loss or damage caused to users either by direct or indirect use of this information. This document may contain information about third party products or processes. This third party information is out of the sphere of influence of CTModule AG. Therefore CTModule AG shall not be responsible for the correctness or legitimacy of this information.

While due care has been taken to deliver accurate documentation, CTModule AG does not warrant that this document is error-free. If you find any errors, inconsistencies, omissions or other problems related to this document, please report this in writing by email to box@ctmodule.com at CTModule AG.

CTMaker, VAS, Callisto, Callisto Express, Callisto ISDN, Callisto One, Callisto UCM, Callisto Cruise, Callisto Hospitality, Callisto X Mobile, COC Express , COC UCM and CTModule AG are trademarks and the CTModule logo is a service mark of CTModule AG.

All other products or company names mentioned herein are used for identification purposes only, and may be trademarks or registered trademarks of their respective owners.

The following description of software, hardware or process of CTModule AG or other third party provider may be included with your product and will be subject to the software, hardware or other license agreement.

Disclaimer

Changes are possible without notice.

The General Terms and Conditions (GTC) of CTModule AG, Switzerland apply.

All rights reserved.

For more information about CTModule AG, visit the CTModule web site at

www.ctmodule.com



CTMODULE

COMMUNICATION TECHNOLOGY MODULES

CTMODULE AG

Lehnweg 1

CH-3123 Belp/Berne

Switzerland

T: +41 (0)31 531 11 11

F: +41 (0)31 531 11 12

sales@ctmodule.com

OFFICE GERMANY

Frankfurter Straße 92

D-65760 Eschborn/Frankfurt

Germany

T: *+49 6196 2049173-0*

F: *+49 6196 2049173-9*

sales-d@ctmodule.com

OFFICE SERBIA

Gospodara Vučića 145

RS-11000 Belgrade

Serbia

T: +381 18 308076

sales@ctmodule.com