CALLISTO

CRUISE WAKE-UP

ADMINISTRATION MANUAL

Table Of Contents

Administration manual 3
Setup 3
Settings 4
Wake-up alerts 7
Reports 10
Copyright Information, Disclaimer 11

Setup

Installation

Cruise Wake-up is installed through Callisto's Open Application Manager. The installation and updating process for OAM applications is described in the chapter Options of the Callisto platform administration manual.

Privileges

The following application privileges can be assigned to a user for the Cruise Wake-up application. For setting user privileges, see the chapter User administration of the Callisto platform administration manual.

Settings	Provides access to the *Settings* tab.
Wakeup	Provides access to the *Wakeup* tab.
Reports	Provides access to the *Reports* tab.

Access

Configure icon

Administrators can access the Cruise Wake-up configuration by navigating to System > Open Application Manager in the main menu. In the tab Applications, locate the Cruise Wake-up instance and click on the *Configure* icon.

Users who were granted privileges to access the Cruise Wake-up instance can do so by navigating to Applications in the main menu and clicking on the name of the Cruise Wake-up instance.

Settings

This tab contains the general settings for wake-up calls.



Setting	Description	Accepted values
Ringtime	Set in seconds. The duration a single phone ring when executing a wake-up call.	5–80 seconds
Repetitions	How often a wake-up call is repeated when remaining unanswered.	0–5 repetitions
Repetitions gap	Set in seconds. The interval to wait	30–600 seconds

Setting	Description	Accepted values
	before a wake-up call is repeated.	
Maximum number of concurrent wakeup setups	Maximum of setups that can be executed at the same time.	0 or more
Maximum number of concurrent wakeup alarms	Maximum of alarms that can be executed at the same time.	0 or more
Use 12-hour clock format	If checked, 12-hour format is used to represent times.	
Detect redirection	If checked, Cruise Wake-up will detect when the wake-up call to a cabin phone is redirected. In this case, the wake-up call is marked as failed (redirected).	
Caller number	The phone number to use as caller ID when a wake-up call is executed.	
Caller name	The name to show on the recipient's phone display when a wake-up call is executed.	
Automatically delete reports after	Set in days. Time after which wake-up reports will be deleted.	

Wake-up alerts

In the *Wakeup* tab, the individual wake-up alerts for each cabin are set. Cabins with active wake-up alerts are colored green, cabins without wake-up alert are colored red.



The view can be filtered by choosing a filter action from the drop-down menu labeled Action in the top left corner.

All Cabins	Show all available cabins.
Cabins with Wakeups	Show cabins for which a wake-up alert is active.
Cabins without Wakeups	Show cabins for which no wake-up alert is active.
Groups	Show the *Group wake-up* view.

Additionally, the list can be filtered by searching for cabin numbers with the text search in the top right corner.

Set wake-up alerts

Various methods are available to set wake-up alerts.



Set wake-up alerts in the Callisto web GUI

Using the Callisto web GUI, a wake-up alert can be set for every cabin phone individually. Clicking on a cabin will open the Add Wakeup dialog window where the following configuration can be set:

Enabled

Time

Execute

This is the recommended method to manage wake-up alerts by front-desk staff.

Set wake-up alerts via phone

Guests and crew members can call the wake-up service number (as defined in the Cruise Base speed-dials) in order to set or edit the time when a wake-up call should occur.

An IVR menu allows the caller to set a wake-up time within the next 24 hours. What language the IVR menu is in depends on the check-in mode:

- If the check-in mode is set to automatic, the language set for the *guest* is used.
- If the check-in mode is set to manual (i.e., Direct Outward Dialing), the language set for the *cabin* is used.

Set wake-up alerts via LCCI

Wake-up calls can be set using 3rd party entertainment systems (e.g., cabin TV systems) if they are integrated in the LCCI system. When setting a wake-up alert this way, LCCI will send a message/request to Callisto to initiate, edit, or delete the alert. Any previously set alerts will be overwritten.

Group wake-up

Choosing the action *Groups* from the Action drop-down menu will show the *Group wake-up* view. In this view, wake-up alerts can be set for entire cabin groups instead of individual cabins. Groups are defined in

the Cruise Base configuration and can only be accessed by users with the appropriate privileges.

Group wake-up alerts are independent from individual wake-up alerts; guests can set individual wake-up alerts for their cabin regardless of the group wake-up settings.

Reports

All actions related to wake-up alerts, such as setting and deleting alerts or alarms being executed, are listed in the *Reports* tab.



The list can be filtered by date/time and by action. Available action filters are:

All	Show all actions related to wake-up alerts.
Set	Show all times an alert has been set.
Delete	Show all times an alert has been deleted.
Alarm	Show all times an alert was executed.

Additionally, using the search field in the top-right corner, the list can be filtered by user, destination, source, or cabin number.

Report lists can be exported as CSV or Excel files by clicking on the respective button in the top-right corner.

Copyright

Copyright © 2026 CTModule AG; All Rights Reserved

This document contains proprietary information of CTModule AG. No part of the work described herein may be reproduced. Reverse engineering of the hardware or software is prohibited and is protected by patent law.

This material or any portion of it may not be copied in any form or by any means, stored in a retrieval system, adopted or transmitted in any form or by any means (electronic, mechanical, photographic, graphic, optic or otherwise), or translated to any language or computer language without the prior written permission of CTModule AG.

The information in this document is subject to change without notice. CTModule AG makes no representation or warranties with respect to the contents herein and shall not be responsible for any loss or damage caused to users either by direct or indirect use of this information. This document may contain information about third party products or processes. This third party information is out of the sphere of influence of CTModule AG. Therefore CTModule AG shall not be responsible for the correctness or legitimacy of this information.

While due care has been taken to deliver accurate documentation, CTModule AG does not warrant that this document is error-free. If you find any errors, inconsistencies, omissions or other problems related to this document, please report this in writing by email to box@ctmodule.com at CTModule AG.

CTMaker, VAS, Callisto, Callisto Express, Callisto ISDN, Callisto One, Callisto UCM, Callisto Cruise, Callisto Hospitality, Callisto X Mobile, COC Express , COC UCM and CTModule AG are trademarks and the CTModule logo is a service mark of CTModule AG.

All other products or company names mentioned herein are used for identification purposes only, and may be trademarks or registered trademarks of their respective owners.

The following description of software, hardware or process of CTModule AG or other third party provider may be included with your product and will be subject to the software, hardware or other license agreement.

Disclaimer

Changes are possible without notice.

The General Terms and Conditions (GTC) of CTModule AG, Switzerland apply.

All rights reserved.

For more information about CTModule AG, visit the CTModule web site at

www.ctmodule.com



CTMODULE

COMMUNICATION TECHNOLOGY MODULES

CTMODULE AG

Lehnweg 1

CH-3123 Belp/Berne

Switzerland

T: +41 (0)31 531 11 11

F: +41 (0)31 531 11 12

sales@ctmodule.com

OFFICE GERMANY

Frankfurter Straße 92

D-65760 Eschborn/Frankfurt

Germany

T: *+49 6196 2049173-0*

F: *+49 6196 2049173-9*

sales-d@ctmodule.com

OFFICE SERBIA

Gospodara Vučića 145

RS-11000 Belgrade

Serbia

T: +381 18 308076

sales@ctmodule.com