

Login

Start the COC Configurator, and then fill in the initial information for the login. In the Address field, enter the IP address of the COC Proxy. In the Username field, enter admin as user name. In the Password field, enter the default password, which is admin. Then click on Connect to connect to the COC Proxy.

After your first login, it is strongly recommended to set a new, secure password. Double-click the user labeled admin from the client list and enter a new password in the Password field. Click the Save button to confirm the change. Additionally, you can create a custom admin user to use for administration activities.