


Settings

The general configuration for BabyPhone is found in the *Settings* tab. These settings are applied for all phones that use this BabyPhone instance.



Settings

BabyPhone

Volume Threshold:

Values are typically in the range 50-2000 depending on the phone setup.

Measurement Period:

Measurement period in milliseconds. Values are typically in the range 500-10000.

Initial Alarm delay:

Minimal time in seconds before the first alarm is generated.

Alarm gap:

Minimal time in seconds between 2 alarms.

Maximum concurrent observations:

Maximum number of observations which can be executed in the same period of time.

Maximum concurrent actions:

Maximum number of actions (Alarm Calls/Calls-In) that can be supported in the same time.

Maximum duration of observation:

Observation will be terminated automatically after this period of time. Values are in range 60-1440 minutes. 0 - this feature is disabled

Notify end observation

Notify when an observation has been ended.

Caller Name:

Name which will be used as caller for babyphone calls

Reset PIN:

PIN which will be used to reset the cabin number on the Android client

Automatically delete reports after (days):

Volume Threshold

The noise level at which the alarm gets triggered. Takes a value between 50 and 2000; A lower value means the alarm gets triggered at a lower noise level.

Set in milliseconds between 500 and 1000. The

Measurement Period

Initial Alarm delay	interval at which the noise level is measured. Set in seconds. Set the delay after activating BabyPhone before it starts observing the noise level.
Alarm gap	Set in seconds. The interval to wait after triggering an alarm and before triggering the alarm again.
Maximum concurrent observations.	The maximum number of simultaneously executable observations (i.e., active noise level checks).
Maximum concurrent actions	The maximum number of simultaneously executable actions (i.e., alarm calls and call-ins).
Maximum duration of observation	Set in minutes between 60 and 1440. The time after which observation mode is automatically terminated. Set to 0 to disable automatic termination.
Notify end observation	If checked, guest will receive a notification after observation mode is terminated.
Caller Name	The name to display when a phone receives an alarm call from BabyPhone.
Reset PIN	The PIN to use for resetting the cabin number on BabyPhone Mobile.
Automatically delete reports after	Set in days. The period after which BabyPhone reports get deleted.