


# Mobile devices

Mobile devices are managed in the *Mobile Handsets* tab. The BabyPhone monitoring service is only available to the devices registered here, so these devices should be distributed to the cabins that use BabyPhone monitoring.



Delete icon

A mobile device can be registered for use with the BabyPhone application by clicking the Add button in the top left corner and removed by clicking the respective delete button on the right side.

## Device setup and usage

1. Use the cabin phone to call the BabyPhone service.  
The BabyPhone service number is the application line which has been assigned to the BabyPhone instance. The number can be reviewed and changed by admin users in the [Open Application Manager](#).
2. Enter the number of a mobile device that is registered in the BabyPhone application, and confirm with the # key. The service is activated after the Initial Alarms Delay has passed (as configured in the [Settings](#) tab).
3. The observing phone (usually the cabin phone), has now entered monitoring mode and is detecting noise. If a sound is detected which is louder than the Volume Threshold defined in the [Settings](#) tab, the mobile device is called.
4. The service keeps running after an alarm call is terminated. The service will call again if the sound still exceeds the threshold.
5. When the Maximum duration of observation is reached, the service will be deactivated. If Notify end observation is enabled, the mobile device is called to notify the guest of the deactivation of the BabyPhone service.

For more details on administration and usage of mobile devices with BabyPhone, refer to the [BabyPhone mobile manual](#).