


Main menu



The main screen of BabyPhone Mobile features a menu button in the top right corner. Touching it reveals the following menu items:

Clear alarm history

Deletes all entries of the BabyPhone Mobile alarm history.

Reset cabin

The dialog window to clear alarm history is also shown every time the mobile device is restarted. Perform a [cabin reset](#). This option is intended to be used by the front desk staff only.

Show instructions

Show the [instruction screen](#) again.

Change language

Change the interface language.

Settings

Enter the application settings menu. The settings that can be configured here are the same as the [parameters that are configured during setup](#).

About

It is possible to hide this menu item by setting the [corresponding parameter](#). It is recommended to hide this item once the application is configured properly. Shows information about the BabyPhone Mobile application and all open source libraries that are being used.