

Setup

Installation

Cruise Alarming is installed through Callisto's Open Application Manager. The installation and updating process for OAM applications is described in the chapter [Options](#) of the Callisto platform administration manual.

Privileges

The following application privileges can be assigned to a user for the Cruise Alarming application. For setting user privileges, see the chapter [User administration](#) of the Callisto platform administration manual.

Settings	Provides access to the <i>Settings</i> tab.
EspaSources	Provides access to the <i>Espa Configuration</i> tab.
ActiveAlarms	Provides access to the <i>Active Alarms</i> tab.
ClearedAlarms	Provides access to the <i>Cleared Alarms</i> tab.
Alarm Groups	Provides access to the <i>Alarm Groups</i> tab.
SMCSIntegration	Provides access to the <i>SMCS Alarm Integrations</i> tab.

Access



Configure icon

Administrators can access the Cruise Alarming configuration by navigating to System > Open Application Manager in the main menu. In the tab Applications, locate the Cruise Alarming instance and click on the *Configure icon*.

Users who were granted privileges to access the Cruise Alarming instance can do so by navigating to Applications in the main menu and clicking on the name of the ProfACD instance.