Activating services

Change to Cisco Unified CallManager Serviceability.

1. Open Tools > Service Activation.
2. Activate both Services Cisco IP Voice Media Streaming App and Cisco AXL Web Service.