



CALLISTO⁺



BABYPHONE

BABYPHONE MOBILE MANUAL

Table Of Contents

BabyPhone Mobile manual.....	3
Overview	3
Setup	5
Main menu	10
Cabin assignment	11
Introduction screen.....	19
Monitoring and listening	22
Copyright Information, Disclaimer.....	27

Overview

BabyPhone Mobile application works as a client for Callisto BabyPhone which uses the cabin phone as a baby monitoring system. Guests can use a mobile device to listen to the room their baby is in, and may receive alarm calls if the cabin phone detects noise in the room.

Usage overview

The baby monitoring setup requires two devices:

- A cabin phone or room phone which is registered as a system phone in Callisto.
- A mobile device running Android with BabyPhone Mobile installed.

The setup is designed to be used with mobile devices that are dedicated for use with BabyPhone: The devices are owned and managed by the ship or hotel and are temporarily handed out to guests when requested.

Before lending a mobile device to the guest, the front desk staff will assign the guest's cabin phone to the mobile device (see chapter [Cabin assignment](#)).

When the cabin phone detects a noise, the guest will get an alarm call on the mobile device. The mobile device can also be used to dial into the cabin phone and listen to the room at any time.

Depending on the configuration, guests can activate BabyPhone by calling the service from the cabin phone or directly via the mobile device.

BabyPhone states

BabyPhone Mobile has the following states:

Not assigned


No guest, cabin, or cabin phone is currently assigned to the mobile device. Assignment is conducted by entering a cabin number or scanning a QR code (see chapter [Cabin assignment](#)). In this state, monitoring mode can be [activated using a cabin phone](#).

Not connected

The mobile device is either not connected to the network or the SIP parameters are not configured correctly.

Connected


Once the mobile device is assigned and connected to a cabin phone, BabyPhone is ready to enter monitoring mode.



For easier understanding, the connection to WLAN and the Callisto server is omitted in the following graphs.


Monitoring mode

The mobile device can actively listen to the room through the cabin phone. It is also ready to receive alert calls.




In-call mode

While in monitoring mode, when the noise threshold in the room is exceeded, the cabin phone transmits an alarm call to the mobile device. Accepting the call will enter listening mode.



Listening mode


The mobile device is currently playing back the sound which the cabin phone is receiving.



Handling incoming calls

By default, any incoming calls other than alarm calls from the assigned cabin phone get blocked by BabyPhone Mobile. Setting the [corresponding parameter](#) can allow incoming external calls.

While the mobile device is in a call, no alarm calls can be received by the BabyPhone service.



Setup

BabyPhone Mobile needs to be installed by an administrator on all mobile devices that are intended to be used with BaybPhone. The application can be installed using any MDMMobile Device Management platform or manually by installing the generated .apk file from the phone's file system. After the application is installed, the several parameters must be set by an administrator. There are multiple methods to set the parameters (see section [Setting parameters](#)).

Required settings

The following parameters are mandatory.

Callisto IP address	The IP address of the Callisto installation. Parameter name: callisto_address MDM console intent: SET_CALLISTO_ADDRESS
Baby phone	The line number associated with the BabyPhone instance in Callisto. Parameter name: baby_phone MDM console intent: SET_BABY_PHONE
Application name	The name of the BabyPhone instance set up in Callisto. Parameter name: app_name MDM console intent: SET_APP_NAME
UCM IP address	The IP address of the UCM associated with Callisto. Parameter name: ucm_address MDM console intent: SET_UCM_ADDRESS
SIP Username	The SIP username as defined on UCM. If auth_type is set to digest, set this parameter to the Directory Number as defined on the UCM. Parameter name: sip_username MDM console intent: SET_SIP_USERNAME
Authentication Type	The authentication type to use. Supported options are: <ul style="list-style-type: none">• Plain text (value: plain)• Digest (value: digest) Parameter name: auth_type MDM console intent: SET_AUTH_TYPE

Authorization Username	Only used if auth_type is set to digest. The digest authorization username defined on the UCM. Parameter name: auth_username
Password	MDM console intent: SET_AUTH_USERNAME The SIP password as defined on the UCM. Parameter name: sip_password MDM console intent: SET_SIP_PASSWORD

Optional settings

The following parameters may be omitted when configuring the application.

Start monitoring by entering Cabin number*	Boolean. If set to true, the staff can manually enter a cabin number to assign a cabin phone to the mobile device. Parameter name: start_monitoring_with_cabin_number MDM console intent: SET_START_MONITORING_WITH_CABIN_NUMBER
Start monitoring by scanning the QR code *	Boolean. If set to true, the staff can use the QR code feature of Callisto BabyPhone to assign a cabin phone to the mobile device. Parameter name: start_monitoring_with_qr_code MDM console intent: SET_START_MONITORING_WITH_QR_CODE
Incoming calls	Boolean. If set to false, any incoming call with a number different to the number set in the baby_phone parameter will be rejected automatically by the mobile device. Default value is false. During active calls, no alarm notifications by the BabyPhone service can be received. Parameter name: incoming_calls
Save logs	MDM console intent: SET_INCOMING_CALLS Boolean. If set to true, logs for BabyPhone Mobile are written. They are saved to a text file on the mobile device in the directory located at InternalStorage/Android/data/com.callistocruise.babyphone/files/BabyPhone/log. Depending on the system of the mobile device, this path may vary.

A new log file is created for every day, and files older than three days are deleted automatically.

Logs are only written when the application is running in the foreground.

Parameter name: save_logs

Hide Settings Menu

MDM console intent: SET_SAVE_LOGS
Boolean. If set to true, the settings menu cannot be accessed from the application menu as a security measure. Default value is false.

Parameter name: hide_settings_menu

Show Welcome Screen

MDM console intent: SET_HIDE_SETTINGS_MENU
Boolean. If set to true, an instruction screen is shown to the user when BabyPhone Mobile launches. Default value is false.

Parameter name: show_welcome_screen

MDM console

intent: SET_SHOW_WELCOME_SCREEN

* Either of these options must be set to true for guests to be able to start monitoring with the mobile device. Otherwise, guests can activate monitoring only over the cabin phone.

Setting parameters

Three methods are available to configure the application with the settings mentioned above:

1. Use an MDM tool and provide the parameters in a configuration scheme.
2. Use an MDM console to set the parameters by firing their corresponding intents.
3. In the BabyPhone mobile application, tap the menu button and navigate to the Settings menu.

The BabyPhone application implements managed configuration settings, so parameters can be configured by setting attributes over the MDM IT admin console.

Using the Settings menu has lower priority than parameters set through MDM: Any settings made in the menu will be overwritten when reconfigured using MDM, and if a configuration scheme exists, the settings in the menu become read-only. Therefore, using the Settings menu is only recommended for testing purposes.

Set the parameters with a configuration schema using *Custom Settings* within VMWare Workspace ONE MDM:

```
<characteristic type="com.airwatch.androidwork.app:com.callistocruise.babyphone
" uuid="568bc89d-1df8-4ce9-a041-e5a24acdb7ec">
  <parm name="callisto_address" vaule="192.168.100.109" type="string">
  <parm name="baby_phone" vaule="9297" type="string">
  <parm name="app_name" vaule="BabyPhone" type="string">
  <parm name="ucm_address" vaule="192.168.100.198" type="string">
  <parm name="sip_username" vaule="1107" type="string">
  <parm name="auth_type" vaule="plain" type="string">
  <parm name="auth_username" vaule="" type="string">
  <parm name="sip_password" vaule="1107" type="string">
```

```

    <parm name="start_monitoring_with_cabin_number" vaule="True" type="boolean"
  >
    <parm name="start_monitoring_with_qr_code" vaule="False" type="boolean">
    <parm name="save_logs" vaule="False" type="boolean">
    <parm name="incoming_calls" vaule="False" type="boolean">
    <parm name="hide_settings" vaule="True" type="boolean">
    <parm name="show_welcome_screen" vaule="True" type="boolean">
  </characteristic>

```

If the configuration schema is not readable by the MDM console, the parameters can also be set using console intents. Each parameter's console intent is listed above.

If the phone is part of an MDM system, configuration using MDM has higher priority than manually set parameters. Manually set parameters will be overwritten if they are present in a configuration scheme.

Set the parameters using SOTI MDM.

```

sendintent -b "intent:#Intent;action=com.callistocruise.babyphone.intent.action
.SET_CALLISTO_ADDRESS;S.callisto_address=192.168.100.109;end;"
sendintent -b "intent:#Intent;action=com.callistocruise.babyphone.intent.action
.SET_BABY_PHONE;S.baby_phone=9297;end;"
sendintent -b "intent:#Intent;action=com.callistocruise.babyphone.intent.action
.SET_APP_NAME;S.app_name=BabyPhone;end;"
sendintent -b "intent:#Intent;action=com.callistocruise.babyphone.intent.action
.SET_UCM_ADDRESS;S.ucm_address=192.168.100.198;end;"
sendintent -b "intent:#Intent;action=com.callistocruise.babyphone.intent.action
.SET_SIP_USERNAME;S.sip_username=1107;end;"
sendintent -b "intent:#Intent;action=com.callistocruise.babyphone.intent.action
.SET_AUTH_TYPE;S.auth_type=digest;end;"
sendintent -b "intent:#Intent;action=com.callistocruise.babyphone.intent.action
.SET_AUTH_USERNAME;S.auth_username=babyphonell107;end;"
sendintent -b "intent:#Intent;action=com.callistocruise.babyphone.intent.action
.SET_SIP_PASSWORD;S.sip_password=1107;end;"
sendintent -b "intent:#Intent;action=com.callistocruise.babyphone.intent.action
.SET_START_MONITORING_WITH_PIN;B.start_monitoring_with_cabin_number=true;end;"
sendintent -b "intent:#Intent;action=com.callistocruise.babyphone.intent.action
.SET_START_MONITORING_WITH_QR_CODE;B.start_monitoring_with_qr_code=true;end;"
sendintent -b "intent:#Intent;action=com.callistocruise.babyphone.intent.action
.SET_SAVE_LOGS;B.save_logs=true;end;"
sendintent -b "intent:#Intent;action=com.callistocruise.babyphone.intent.action
.SET_INCOMING_CALLS;B.incoming_calls=false;end;"
sendintent -b "intent:#Intent;action=com.callistocruise.babyphone.intent.action
.SET_HIDE_SETTINGS_MENU;B.hide_settings_menu=true;end;"
sendintent -b "intent:#Intent;action=com.callistocruise.babyphone.intent.action
.SET_SHOW_WELCOME_SCREEN;B.show_welcome_screen=true;end;"

```

Set the parameters using VMWare Workspace ONE MDM.

```

mode=implicit,broadcast=true,action=com.callistocruise.babyphone.intent.action.
SET_CALLISTO_ADDRESS,extraString=callisto_address=192.168.100.109
mode=implicit,broadcast=true,action=com.callistocruise.babyphone.intent.action.
SET_BABY_PHONE,extraString=baby_phone=9297
mode=implicit,broadcast=true,action=com.callistocruise.babyphone.intent.action.
SET_APP_NAME,extraString=app_name=BabyPhone

```

```
mode=implicit,broadcast=true,action=com.callistocruise.babyphone.intent.action.SET_UCM_ADDRESS,extraString=ucm_address=192.168.100.198
mode=implicit,broadcast=true,action=com.callistocruise.babyphone.intent.action.SET_SIP_USERNAME,extraString=sip_username=1107
mode=implicit,broadcast=true,action=com.callistocruise.babyphone.intent.action.SET_AUTH_TYPE,extraString=auth_type=plain
mode=implicit,broadcast=true,action=com.callistocruise.babyphone.intent.action.SET_AUTH_USERNAME,extraString=auth_username=babyphone1107
mode=implicit,broadcast=true,action=com.callistocruise.babyphone.intent.action.SET_SIP_PASSWORD,extraString=sip_password=1107
mode=implicit,broadcast=true,action=com.callistocruise.babyphone.intent.action.SET_START_MONITORING_WITH_PIN,extraBoolean=start_monitoring_with_cabin_number=true
mode=implicit,broadcast=true,action=com.callistocruise.babyphone.intent.action.SET_START_MONITORING_WITH_QR_CODE,extraBoolean=start_monitoring_with_qr_code=true
mode=implicit,broadcast=true,action=com.callistocruise.babyphone.intent.action.SET_SAVE_LOGS,extraBoolean=save_logs=true
mode=implicit,broadcast=true,action=com.callistocruise.babyphone.intent.action.SET_INCOMING_CALLS,extraBoolean=incoming_calls=false
mode=implicit,broadcast=true,action=com.callistocruise.babyphone.intent.action.SET_HIDE_SETTINGS_MENU,extraBoolean=hide_settings_menu=true
mode=implicit,broadcast=true,action=com.callistocruise.babyphone.intent.action.SET_SHOW_WELCOME_SCREEN,extraBoolean=show_welcome_screen=true
```


Once all required application parameters are set up, the BabyPhone service becomes active and is ready to enter monitoring mode. The service can be terminated by navigating to the Phone Settings > Apps, locating the BabyPhone application and choosing Force Stop.

Additional settings

Since the Android operating system is open-source software, it might be necessary to configure additional settings or permissions depending on the version and distribution.

To work properly, BabyPhone Mobile needs permission to show notifications in any phone state (including lock screen etc.), and it needs to be able to run services without any interruption. This is especially important when power saving tools are active on the phone; since such tools might suspend or stop application services, make sure that BabyPhone Mobile is not affected.

Main menu



The main screen of BabyPhone Mobile features a menu button in the top right corner. Touching it reveals the following menu items:

Clear alarm history

Deletes all entries of the BabyPhone Mobile alarm history.

Reset cabin

The dialog window to clear alarm history is also shown every time the mobile device is restarted. Perform a [cabin reset](#). This option is intended to be used by the front desk staff only.

Show instructions

Show the [instruction screen](#) again.

Change language

Change the interface language.

Settings

Enter the application settings menu. The settings that can be configured here are the same as the [parameters that are configured during setup](#).

About

It is possible to hide this menu item by setting the [corresponding parameter](#). It is recommended to hide this item once the application is configured properly. Shows information about the BabyPhone Mobile application and all open source libraries that are being used.

Cabin assignment


Once BabyPhone Mobile is installed on a mobile device and all parameters have been set, a cabin phone can be assigned to the mobile device. The cabin phone will act as monitoring device, allowing to transmit the noise from the room to the mobile device.


Cabin assignment must be done by the front desk staff before handing over the mobile device to the passenger. If no cabin assignment is conducted, monitoring mode can only be [activated using a cabin phone](#).

There are two methods to assign a cabin phone to the mobile device. Which methods are available depends on the configuration of the [settings parameters](#).

Assignment by cabin number

If the parameter `start_monitoring_with_cabin_number` is set to true, the main screen of BabyPhone mobile will show a button labeled Enter Cabin Number. Press the button and enter the passenger's cabin number to assign the corresponding cabin phone to the mobile device.





Assignment by QR code

If the parameter `start_monitoring_with_qr_code` is set to true, the main screen of BabyPhone mobile will show a button labeled Scan QR Code. The QR code for cabin assignment can be generated in the BabyPhone instance on Callisto by navigating to the tab [QR Code](#). In the search field, enter a cabin number or passenger name and select the passenger to assign to the mobile device from the search results. A QR code is generated automatically.

 **QR Code** BabyPhone




🔍 101|


Anna Hale 10122


Joseph Reed 10157

Cindy Campbell 10171

On the mobile device, press the button Scan QR Code and scan the QR code generated in Callisto to assign the corresponding cabin phone to the mobile device. After successful assignment, the QR code will display a green check mark.



 **QR Code** BabyPhone



Anna Hale 10122

The information contained in the QR code is only the cabin number of the following format:

```
<?xml version = "1.0" encoding="utf-8"?>
<BabyPhoneConfiguration>
  <cabinNumber><cabin number></cabinNumber>
</BabyPhoneConfiguration>
```


This configuration data can be part of any other XML.

Statuses

The main screen will show the cabin number in the top left corner once the cabin phone is assigned

successfully. The colored top part of the screen indicates the current application status:


- Blue indicates that the application is properly set up and connected. From this status, BabyPhone Mobile can enter [monitoring mode](#).
- Green indicates that the application is currently in monitoring mode.
- Gray indicates that the device is either not connected to the network or that the SIP parameters are not configured correctly.



Reset cabin

After a guest returns the mobile device to the staff, a cabin reset must be performed before handing out the mobile device to another guest. Performing a cabin reset resets the assignment of the cabin phone and deletes the complete alarm call history.

To perform a cabin reset, touch the [main menu](#) button and select Reset Cabin. A window will pop up, prompting you to enter the reset PIN which is set in the [Callisto BabyPhone application](#). After a successful cabin reset, a text reading "No Cabin Assigned" is displayed in the top left corner of the mobile application's screen.



name which will be used as caller for babyphone calls

Reset PIN:

PIN wich will be used to reset the cabin number on the Android client


Automatically delete reports after (days):


The reset PIN can be found in the *Settings* tab of the BabyPhone instance on Callisto.

Introduction screen

Instruction screen

When the device is ready to be handed over from the staff to the guest, BabyPhone Mobile will display an instruction screen. Thus, the guest can read the instructions before using BabyPhone Mobile.





There are two different versions of the instruction text. Which text is shown depends on the [parameters](#).

- If either `start_monitoring_with_cabin_number` or `start_monitoring_with_qr_code` is set to true, the introduction describes how to [activate monitoring from the mobile device](#).
- If both those parameters are set to false (i.e., no cabin assignment is conducted), the introduction describes how to [activate monitoring from the cabin phone](#).
- If `show_welcome_screen` is set to false, no introduction is shown.


The background image of the instructions screen can be customized. To use a custom background image, place the file at the following path.

`http://<callisto>/Applications/startup/<babyphone>/img/mobile_instructions_bkgd.jpg`

`<callisto>` is the address of the Callisto installation and `<babyphone>` the name of the BabyPhone

application instance.

Monitoring and listening



The application in monitoring mode.

In monitoring mode, the mobile device is connected to a cabin phone and ready to listen to it. In this mode, BabyPhone Mobile is also ready to receive alarm calls when the volume threshold is exceeded.

Activate monitoring using the mobile device

Monitoring mode can be activated once a [cabin phone has been assigned to the mobile device](#) and the cabin phone is connected to the same network as the Callisto system.



If a cabin phone has been assigned to the mobile device, a button labeled Start Monitoring is available on the mobile screen. Touch this button to enter monitoring mode.

Activate monitoring using the cabin phone

Monitoring mode can be activated once a [cabin phone has been assigned to the mobile device](#) and the cabin phone is connected to the same network as the Callisto system.

This method is available by default. On the cabin phone, enter the BabyPhone service number. A voice menu will prompt you to enter the mobile device's SIP number, followed by the pound sign #.


The BabyPhone service number is the application line which has been assigned to the BabyPhone instance. The number can be reviewed and changed by admin users in the [Open Application Manager](#). The numbers of all mobile devices can be reviewed and changed in the [Mobile Handsets](#) tab of Callisto BabyPhone.

The service number of BabyPhone is set to 8826. The mobile device has the SIP number 4002. To activate monitoring mode on this mobile device, the guest must dial 8826 on the cabin phone, and after receiving an introduction from the voice menu, press 4002#.


Listening mode

 LISTEN TO THE ROOM

When in monitoring mode, the device is ready to listen to the room. Listening mode can be entered manually by touching the button labeled Listen to the Room or when receiving an alarm call.



Listening mode activated manually.




Listening mode activated by accepting an incoming alarm call.

While listening, the sound recorded by the cabin phone is played back on the mobile device. Touching the Play on Speaker button plays the sound on the mobile device's speaker, **Stop Listening** will leave listening mode and return to monitoring mode.


Alarm calls

When the volume threshold defined in the BabyPhone settings is exceeded, the cabin phone will initiate an alarm call to the mobile device and BabyPhone Mobile will enter *in-call mode*.

If the alarm call is received while the mobile device is locked, a full-screen notification will appear. If the device is unlocked, the alarm will appear as a pop-up at the top of the screen. In both cases, the guest can accept or decline the alarm call.



Incoming alarm when the mobile device is locked.



Incoming alarm when the mobile device is unlocked.

Stop monitoring

To leave monitoring mode, hang up the cabin phone which is assigned to the mobile device.

Copyright

Copyright © 2026 CTModule AG; All Rights Reserved

This document contains proprietary information of CTModule AG. No part of the work described herein may be reproduced. Reverse engineering of the hardware or software is prohibited and is protected by patent law.

This material or any portion of it may not be copied in any form or by any means, stored in a retrieval system, adopted or transmitted in any form or by any means (electronic, mechanical, photographic, graphic, optic or otherwise), or translated to any language or computer language without the prior written permission of CTModule AG.

The information in this document is subject to change without notice. CTModule AG makes no representation or warranties with respect to the contents herein and shall not be responsible for any loss or damage caused to users either by direct or indirect use of this information. This document may contain information about third party products or processes. This third party information is out of the sphere of influence of CTModule AG. Therefore CTModule AG shall not be responsible for the correctness or legitimacy of this information.

While due care has been taken to deliver accurate documentation, CTModule AG does not warrant that this document is error-free. If you find any errors, inconsistencies, omissions or other problems related to this document, please report this in writing by email to box@ctmodule.com at CTModule AG.

CTMaker, VAS, Callisto, Callisto Express, Callisto ISDN, Callisto One, Callisto UCM, Callisto Cruise, Callisto Hospitality, Callisto X Mobile, COC Express , COC UCM and CTModule AG are trademarks and the CTModule logo is a service mark of CTModule AG.

All other products or company names mentioned herein are used for identification purposes only, and may be trademarks or registered trademarks of their respective owners.

The following description of software, hardware or process of CTModule AG or other third party provider may be included with your product and will be subject to the software, hardware or other license agreement.

Disclaimer


Changes are possible without notice.

The General Terms and Conditions (GTC) of CTModule AG, Switzerland apply.

All rights reserved.

For more information about CTModule AG, visit the CTModule web site at

www.ctmodule.com



CTMODULE⁺

COMMUNICATION TECHNOLOGY MODULES

CTMODULE AG

Lehnweg 1

CH-3123 Belp/Berne

Switzerland

T: +41 (0)31 531 11 11

F: +41 (0)31 531 11 12

sales@ctmodule.com

OFFICE GERMANY

Frankfurter Straße 92

D-65760 Eschborn/Frankfurt

Germany

T: +49 6196 2049173-0

F: +49 6196 2049173-9

sales-d@ctmodule.com

OFFICE SERBIA

Gospodara Vučića 145

RS-11000 Belgrade

Serbia

T: +381 18 308076

sales@ctmodule.com